


【教室投影訊號切換教學】 How To Switch Projector Signal

若投影畫面出現無線投影 wifi 等相關訊息(如下圖)：
If you see the following picture.

二教教具室
Teaching Aid Room
分機(Extension) : 1121



1. 請確認電腦或筆電已開機，並且電腦影像(RGB)線路已接妥。
Please make sure the computer or laptop is turned on and the computer image (RGB) line is connected.



2. 切換投影機控制整合器「電腦 1」或「電腦 2」或「視訊」或「自動」。(ps.少數教室無安裝壁面控制整合器，請使用遙控器操作。)
Switch the projector control integrator "Computer 1", "Computer 2", "Video" or "Auto" on the wall.
(A few classrooms don't have a control integrator installed, please use the remote control.replaced)

